

CNC3040T controller block diagram

WARNINGS:

- 1. Spindle connector can be HOT (connected to mains active) even with switch OFF!
- 2. Cabinet external metal is NOT grounded!

